


Project Overview




CO Detector

Project Overview



TGS5342 Carbon Monoxide Sensor



Reference Circuit




Carbon Monoxide Detector (Marine)




Safety Certifications


System Diagram




Generic Data Acquisition System




CO Detector Black Box




CO Detector System Diagram




Analog Signal Processing



CO Sensor Circuit






Sensor Equivalent Circuit



Simple Single-Ended Op-Amp Circuit




Analog Signal Processing

Negative Feedback






Analog Signal Processing


Negative Feedback





Analog Signal Processing

Negative Feedback











Signal Path Implementation




Signal Path Implementation Improvements



Signal Path Implementation Improvements

- Guarded Traces



Example In-Amp with Guarded Inputs

Image: <https://www.ti.com/lit/ds/sbos034/sbos034.pdf?ts=1588264952402>

BURR-BROWN®
BB



INA116

Ultra Low Input Bias Current INSTRUMENTATION AMPLIFIER

FEATURES

- LOW INPUT BIAS CURRENT: 3fA typ
- BUFFERED GUARD DRIVE PINS
- LOW OFFSET VOLTAGE: 2mV max
- HIGH COMMON-MODE REJECTION: 84dB (G = 10)
- LOW QUIESCENT CURRENT: 1mA
- INPUT OVER-VOLTAGE PROTECTION: ±40V

DESCRIPTION

The INA116 is a complete monolithic FET-input instrumentation amplifier with extremely low input bias current. *Difet*® inputs and special guarding techniques yield input bias currents of 3fA at 25°C, and only 25fA at 85°C. Its 3-op amp topology allows gains to be set from 1 to 1000 by connecting a single external resistor.

Guard pins adjacent to both input connections can be used to drive circuit board and input cable guards to maintain extremely low input bias current.

Signal Path Implementation Improvements

- Analog Ground Plane**




Image: <https://www.analog.com/media/en/training-seminars/design-handbooks/designers-guide-instrument-amps-ch1.pdf>

Decoupling Caps with Complimentary Frequency Response







Image: <https://www.teledyne-e2v.com/content/uploads/2014/09/Board-Layout.pdf>

Isolation of Analog and Digital Ground Return Current






Images: <https://www.analog.com/en/analog-dialogue/studentzone/studentzone-may-2017.html>

Capacitor Frequency Response

Actual Capacitor Equivalent Circuit

Signal Path Implementation Improvements

- **Self Test**




Sensor Circuit

- **Mechanical relay enables connection to self-test current source.**


ADC




Physical Restrictions



Cypress PSoC1 CY8C24223A




DELSIG8 8-Bit Delta Sigma ADC




Physical Restriction: Power

Restriction	Value	Units
Energy capacity of two AA batteries	7.8	Wh
Energy capacity of two AA batteries (90% efficiency)	7.0	Wh
Current capacity at 3.3V	2.1	Ah
MCU current draw while active	6.0	mA
MCU current draw while in sleep	25	uA
Minimum interval between battery replacements	1	year
Max seconds with MCU active	1.15E+06	sec
Min seconds with MCU in sleep	30.39E+06	sec
Percent active	3.6	%




Physical Restriction: Time


Restriction	Value	Units
Minimum ADC sample conversion time	31.25	us
Minimum MCU wake + sample time (estimated)	100	us
Sleep time (from ratio)	2.74	ms
Minimum sample interval time (100us + 2.74ms)	2.75	ms
Maximum sample rate	352	Hz




Sampling Rate & Nyquist-Shannon Theorem




Frequency Aliasing




Frequency Aliasing




Frequency Aliasing



Frequency Aliasing




Frequency Aliasing




Anti-Aliasing Option 1: Precision Analog

High-order analog “anti-aliasing”
filter before ADC




Anti-Aliasing Option 2: Oversampling

Low-order analog “anti-aliasing”
filter before ADC



High-order digital filter after ADC



Signal Band of Interest

Decay time-constant for
stable sensor reading:

$\tau \approx 10$ seconds

$f \approx 0.1$ Hz







Image: https://www.figaro.co.jp/en/product/docs/tgs5141-p00_technical%20infomation%28en%29_rev05.pdf

Physical Restriction: Resolution

Restriction	Value	Units
ADC bit resolution	8	bit
Band of interest	0.3	Hz
Maximum sample frequency	352	Hz
Percent size of least significant bit (1 / 2^8)	0.39	%
Amplitude of least significant bit	-48	dB





Digital Signal Processing





Finite Impulse Response (FIR)

- Function of input only: unconditionally stable.
- High-order FIR filters require large number of taps.
- Introduces larger phase delay than IIR filter.



Infinite Impulse Response (IIR)

- Function of both input and output; can be unstable.
- High-order FIR filter requires low number of taps.



Moving Average Filter

- Simplest FIR filter.
- Flat time-domain response.

$$y[n] = \frac{1}{4}x[n] + \frac{1}{4}x[n-1] + \frac{1}{4}x[n-2] + \frac{1}{4}x[n-3]$$




Image: <https://ptolemy.berkeley.edu/eecs20/week12/freqResponseRA.html>

Windowed Sinc Filter

- Coefficients of a sinc function scaled by a window function.






Image: <https://tomroelandts.com/articles/how-to-create-a-simple-low-pass-filter>


Logic Implementation



CO Detector Algorithm



0 ppm	Recommended Safe Level
6 ppm	WHO 24 Hour Average
9 ppm	ASHRA 8 Hour Average EPA 8 hour 8 Hour Average NAAQS 8 Hour Average WHO 8 Hour Average
25 ppm	ACGIH 8 Hour Average
30 ppm	WHO 1 Hour Average
35 ppm	NIOSH 8 Hour Average NAAQS 1 Hour Average
50 ppm	OSHA 8 hour Average (PEL)
30-69 ppm	UL 30 Day Alarm
87 ppm	WHO 15 Minute Average
70-149 ppm	UL 1-4 Hour Alarm
200 ppm	NIOSH 15 minute STEL
150-399 ppm	UL 10-50 Minute Alarm
400+ ppm	UL 4 Minute Alarm
800 ppm	
1,600 ppm	
3,200 ppm	
6,400 ppm	
12,800 ppm	



Review & Questions